

3sixT

User Guide Long Arm Car Mount

3S-0564

1

Clean area where 3S-0564 will be placed with a dry cloth.



2

Place the screw in sleeve over the suction base ball.


Together, place the suction mount ball into the socket and push in until it clicks into place.

Thread the screw sleeve and tighten hand tight.




3

Remove the suction caps plastic protective covering & flick up the locking lever on the suction mount. Push into place & push lever down when in place to secure.




4

Push the button on the rear of the cradle section to release the arm clamps.




5

When clamps are in the open position, place your device between the clamp arms and squeeze towards your device to secure.



6

To release your device press the button at the rear of the cradle section



7

If mounting on dashboards is more suitable, utilise the included dash mount disc.

Clean area with a dry cloth, remove protective plastic on the disc and stick down into position.

Affix the suction mount to this disc for a secure dash mounted position.

